HYDR@CLEAR

Strap Fitting Instructions

Always fit straps manufactured and supplied by Dawbarn.

- a Feed the side straps from the back of the pole and through the sheet cut-out
- **b** Open sheet using remote control to fully open position, feeding the front and rear straps through the cut-outs
- C Using remote control turn the side motor 1.5 turns anti-clockwise to feed the front and rear straps onto the drum
- d Pull straps tight around the pole and clamp in place
- e Feed strap through the back plate with studs. Fit 2-hole washer over strap onto plate. Feed strap back over the washer. Fit 2nd 2-hole washer over the strap and bolt into place
- f Close sheet with remote control
- **g** Check sheet seals tightly over front and rear hoods and that straps are tight
- h Cut off excess side strap webbing and cable tie in place

For assistance please call 01945 461741











